

A window glass break-in alarm monitor.

DX-155

WINDOW ALERT

Features:

- Sensitive motion sensor detects intruder break-ins at a window.
- Easily attachable to windows.
- · Loud 95 dB alarm.

To Install Battery:

Open the battery cover from the front and install the included $3 \times 1.5 \text{V}$ button cells (AG13, LR44 or , A76).

To Operate

- Attach the Window Alert to the window by using the double-sided foam tape.
- Turn the switch to the on position. After 5 seconds, you'll know the Alert is in "ON mode" when you hear one beeping sound.
- The Alert will be activated for 20 seconds every time the sensor detects unauthorized window moving or knocking.
- To ensure the Alert is working properly, always test the alert's battery status by knocking the window slightly.

Warning:

- This high decibel alarm can injure your ear if you are too close!
- This alarm contains little parts not suitable for small children.

fade in China



